Holo Board (75 Inch) User Manual

Product Model: JJ-F67-T

1 Packing List



Main Components



Accessories



Ver. 1.0.2

2.1 Environment

🖉 🭳 PQ Labs

Q PQ Labs

For the best user experience, please place the Holo Board with approx.3.2 feet/ 1m from your conference table, also keep the middle of the Holo Board aligned to the middle of the conference table.



2.2 Installation Procedure

HoloBoard can be installed as wall mount or floor stand. Please choose accordingly based on your preference.

a. Wall mount: Please use your own wall mount bracket (support up to 66 kg)

```
- 🕂 CAUTION -
```

Please install the M6 Bolt to the VESA screw hole before install your wall mount bracket.



b. Floor stand: sold separately, please refer to the installation guide of the floor stand.



3 Start to use Holo Board



- 🕂 CAUTION -

Holo Board will start automatically once powered on.

Holo Board supports two boot methods

a) Press the 🕑 button of your remote controller to power the Holo Board, the system will start automatically, if the Holo Board displays a "no signal" message with a blue screen, please press the power button once and it will light on.



b) You can press the power button at the left side of the Holo Board.